

## ANNEXURE

### Overboot/Shoe over

- The material used is able to withstand after contacting with dilute sulphuric Acid and also the inner lining of the gloves must be smooth enough to give a soft feeling while using the same.
- The length of the shoe cover shall be 45 cm from the heel.
- The mouth of the Shoe cover should be elastic and it must fit to the legs.

**Model No: Michrochem 3000 with Tie**

1  
Phanikumar